

How To: Reset service indicator D9



1. Switch ignition off
2. Press and hold button (A)
3. Switch ignition on (Pos II)
4. Keep button (A) depressed
5. Display (B) will count down from 10 to 0
6. After keeping button (A) depressed for 10 seconds display will read 0, release button (A)
7. Switch ignition off for 5 seconds, then back on, 'spanner' symbol will now be reset